

**SDD**  
SilcaDiagnosticDevice

**SBB**

**SW- VAG<sup>®</sup> GROUP-L0 (SDD/SBB)**

Code: D431375XA - Vers. 2.0

GB

# INDEX

<b>1</b>	<b>VAG FUNCTIONS MENU (AUDI® - SEAT® - SKODA® - VOLKSVAGEN®)</b> .....	<b>3</b>
1.1	VAG GROUP .....	3
1.2	PROGRAMMING NEW KEYS.....	5
1.3	NUMBER OF KEYS MEMORIZED.....	8
1.4	READING IMMO ID.....	9
1.5	ERRORS .....	10
1.6	ERASE ERRORS .....	11

# 1 VAG FUNCTIONS MENU (AUDI®-SEAT®-SKODA®-VOLKSWAGEN®)

## 1.1 VAG GROUP

The functions on these vehicles are:


- Programme new keys (max. 8 keys in the memory);
- Reading of the number of keys memorized;
- Read IMMO ID;
- Read the errors present;
- Delete all errors.

To make use of this function, use:

	 <p style="text-align: center;">Switch Adapter</p>
 <p style="text-align: center;">CABLE OBDII [00] (STANDARD)</p>	 <p style="text-align: center;">CABLE VAG [01] (OPTIONAL)</p>
<p style="text-align: center;">New key/s All keys to be enabled (Max 8)</p>	<p style="text-align: center;"><b>PIN CODE</b></p> <p style="text-align: center;">Comprising 4 alphanumeric characters</p> <p style="text-align: center;">On the label together with the mechanical code If applied for to the dealer, it will have 7 numbers and will have to use the function : CONV. 7-4</p>

<b>SBB</b>	<b>CABLE/ADAPTER</b>
	 <p style="text-align: center;">CABLE OBD II [00] (STANDARD)</p>
	 <p style="text-align: center;">CABLE VAG [01] (OPTIONAL)</p>


**WHERE TO FIND THE PLUG DIAGNOSTICS**



## SELECTING THE CAR MAKE

In this case SDD/SBB is able to automatically recognize the various central units connected and therefore uses the right communication procedure. Simply identify:

- CAR MODEL
- YEAR OF MANUFACTURE



- Use the ↑↓ arrow keys to select the make, then press **ENTER**.
- Press **ESC** to quit.

## FUNCTIONS MENU


This section allows the functions to be carried out, in particular to:

- programme new keys in the immobilizer also when all the original keys are missing;
- erase the code for a missing key from the immobilizer memory;
- check how many keys are stored in the immobilizer memory;
- view the immobilizer ID (ID IMMO);
- erase any errors in the immobilizer memory.

**ATTENTION:** the programming system for the VAG® group is structured so that **every time programming takes place all the keys that will be used on the given car must be memorized again**. It is therefore not possible to add/erase a single key individually.

**If the wrong PIN CODE is entered 3 times consecutively, the immobilizer unit will block. To release it, leave the key in the ON position (from 30 minutes to 24 hours, according to the vehicle).**

The following is the structure of the VAG® function menu:




- Select and press **ENTER**.

## 1.2 PROGRAMMING NEW KEYS

This function can be used to add keys to the immobilizer or erase them.

- To activate the function select "**PROG. NEW KEYS**" and press **ENTER**.

The display will show:



The **PIN CODE** is required (secret number with 4 digits).

The **PIN CODE** is located on the black plastic tag provided with the car key on purchase. The tag gives the mechanical code and the **PIN CODE** protected by a black plastic film (scrape off with a coin).

If the **PIN CODE** is lost, apply to a **VAG®** dealer for another one.

- press **ESC** to quit;
- press **ENTER** to continue.

The display will show:

```
- DATES INSERTION -
PIN CODE           : XXXX
Keys number        : Y

PIN                : XXXX
N. Keys            : Y

↶ ↷
```

- Enter the **PIN CODE** and press **ENTER**;
- Enter the **Number of keys** to be stored in the memory and press **ENTER**;
- Press **ESC** to quit;
- Press **ENTER** to continue.

The display will show:

```
CONNECTING ...

# # # # # # # # # #
```

- Wait a few seconds to communicate with the immobilizer.

If a wrong PIN has been entered or there are errors during communication, the display will show: **error message No. 1** (see Operating Manual chap. 10 – WARNING/ERROR MESSAGES).

## MEMORIZING KEYS

If communication has been successful, the display will show:

```
COMMUNICATION OK!

Sequentially insert
the keys and turn each
one to the ON position

Press any key ...
```

Memorization of the keys in the car will now begin.

- **Insert all the keys to be memorized one after the other, turning each one to the ON position.**  
If errors occur during programming, the immobilizer warning light (located on the dashboard) will flash rapidly. Repeat the operation.
- Press a key to continue; the display will show:

If the warning light on the console is blinking repeat the procedure because an error with the keys has occurred

Press any key...

## KEY TESTING

**ATTENTION:** to check that the memorized keys work, test by turning on the car engine. If there are problems, repeat the operation.

- Press a key to continue.

## ARCHIVING OPERATIONS - USER DATA

All the operations carried out can be stored in the machine memory.

The display will show:

```
Do you want to save
the customer data

      NO
    >YES

      ↑↓⇒
```

- Select YES/NO and press **ENTER**.
- **No**, to return to the IMMOBILIZER functions menu screen;
- **Yes**, to memorize the data relating to the operation completed;
- **ESC** to quit.

The display will show:

```
Do you want to save
PIN CODE?

      NO
    >YES

      ↑↓⇒
```

- Select YES/NO and press **ENTER**.
- **No**, the data are archived **except for the PIN CODE**.
- **Yes**, the user data are archived.

## USER DATA ARCHIVE

This section is used to enter the user data to be saved for the operation completed;

The display will show:

```
- USER DATA -
POS.: 001
DATE: 19/07/01
> SURNAME: XXXXXXXXXXXX
NAME: XXXXXXXXXXXX
REG.NO: XXXXXXXXXXXX

      ↑↓⇒
```

- SURNAME (required) (**12 characters**);
- NAME/NUMBER PLATE (optional) (**12 characters**).

The following data will be saved automatically:

- **POS.:** Position in which the data will be saved;
- **DATA:** Date of the operation;
- **MAKE:** Car make for which the keys has been memorized;
- **MODEL:** Car for which the keys has been memorized;
- **YEAR:** of the model;
- **Keys mem.:** Number of keys memorized;
- **PIN CODE:** (if memorization is confirmed by the operator);
- **IMMO ID:** Immobilizer identification.

To enter the data:

- use the keys  $\uparrow\downarrow$  to position the cursor on the item required;
- press  $\Rightarrow$  to enter and select the field in which to digit the text.

**NOTE: to select the letter required, press the corresponding key N times.**

The programming capacity of the archive is approx. around 100 users data.

#### Glossary:

<b>Ô:</b>	Deletes characters to the left of the cursor
<b>1</b>	space - . 1
<b>2</b>	A B C 2 à Á á â Ç
<b>3</b>	D E F 3 è È ê ë
<b>4</b>	G H I 4 ì í î ï
<b>5</b>	J K L 5
<b>6</b>	M N O 6 ò ó ô õ Ñ
<b>7</b>	P Q R S 7 ß
<b>8</b>	T U V 8 ù ú û ü
<b>9</b>	W X Y Z 9
<b>0</b>	0

- Press **ENTER** to confirm.
- To quit and memorize the data, press **ESC**.
- Select **YES/NO** and press **ENTER**.

Is the information  
inserted correct?

NO  
>YES

$\uparrow\downarrow\Rightarrow$

- **No**, to return to the data entry screen.
- **Yes**, to store the data in the archive.

### 1.3 NUMBER OF KEYS MEMORIZED

This function is used to view the number of keys memorized in the immobilizer.  
After selection the display will show:

```

- MEM.KEYS NUMBER -
If you don't have
PIN CODE you don't
codify any key

```

The **PIN CODE** is required to use this function.

- press **ESC** to quit
- press **ENTER** to continue

The display will show:

```

- DATES INSERTION -
PIN CODE      : XXXX
PIN           : XXXX

```

- Enter the **PIN CODE**
- press **ESC** to quit;
- press **ENTER** to continue.

The display will show:

```

CONNECTING ...

# # # # # # # # # #

```

At the end of the operation the display will show:

```

Keys number in
memory:

Y

Press any key...

```

- Press a key to quit.

**NOTE:** this function can be used to start the car with an **emergency start**. Enter the PIN CODE and read the number of keys, at the end of the operation the car can be started once, excluding the immobilizer function (using a key without transponder or with disabled transponder).

If a wrong PIN has been entered or there are errors during communication, the display will show: **error message No. 1** (see Operating Manual chap. 10 – WARNING/ERROR MESSAGES).

## 1.4 READING IMMO ID

This function is used to view the **immobilizer identification (ID IMMO)**, a code comprising 14 alphanumeric characters, essential for finding the **PIN CODE**; In such cases the **PIN CODE** is issued by the car manufacturer.

- Select and press ENTER, the display will show:

```
- IMMO ID READING -  
XXXXXXXXXX  
  
IMMO XXXXXXXX  
XXXXXXXX XX  
  
Press ESC to quit
```

Only the next 14 characters make up the word **IMMO** relating to immobilizer identification.

- Press **ESC** to quit.

## 1.5 ERRORS

This function is used to check for any anomalies in the immobilizer memory.

After selection press **ENTER**, the display will show:

```
Please wait:  
Present errors
```

### NO ERRORS

If there are no anomalies in the memory, the display will show:

```
- PRESENT ERRORS -  
  
NO ERROR  
DETECTED  
  
Press any key...
```


- Press any key.

### ERRORS FOUND

If there are anomalies in the memory the display will show how many (XX) errors there are in the centralized unit memory:

```
- PRESENT ERRORS -  
  
Detected  
XX  
errors  
  
Press any key...
```


Press any key to view a description of the error:



- **ERR: XXXXXXXXXXXX**: error code.
- Press **↑↓←→** to scroll all the errors found in the memory;
- Press **ESC** to quit.


## 1.6 ERASE ERRORS

After selection press **ENTER** the display will show:



- Select YES/NO and press **ENTER**.
- **No**, to return to the previous menu.
- **Yes**, to erase the errors in the memory.
- **ESC** to quit.

After a few seconds the display will show:



- Press **ESC** to quit.



**SILCA S.p.A.**  
Via Podgora, 20 (Z.I.)  
31029 VITTORIO VENETO (TV)  
Tel. 0438 9136 Fax 0438 913800  
[www.silca.it](http://www.silca.it)

In the United Kingdom  
**SILCA Ltd.**  
Kimpton Road - Sutton  
SURREY SM3 9QP  
Tel. 0208 6416515  
Fax 0208 6441181  
E-mail: [sales@silcald.co.uk](mailto:sales@silcald.co.uk)

In Germany  
**SILCA GmbH**  
Siemensstrasse, 33  
42551 VELBERT  
Tel. 02051 2710  
Fax 02051 271172  
E-mail: [info@silca.de](mailto:info@silca.de)

In France  
**SILCA S.A.**  
78440 PORCHEVILLE  
Tel. 01 30983500  
Fax 01 30983501  
E-mail: [info@silca.fr](mailto:info@silca.fr)

In Spain  
**SILCA KEY SYSTEMS S.A.**  
C/Santander 73A  
BARCELONA - SPAIN  
Tel. 0034 934981400  
Fax 0034 932788004  
E-mail: [silca@silca.es](mailto:silca@silca.es)

Members of the Kaba Group

